


# Aire Jax Touché

## connection diagram for a working system



The larger the air lines you use, the faster your bags will fill and drain. Internal valve design will handle 1/2" OD hose. All port connections are 3/8" NPT except the gauge port is 1/8" NPT. Install a filter in your supply line to increase the life of your system. We recommend you have a good anti-sway bar in the front and rear when using a front/rear, two valve system to improve control when making turns. Occasionally, new valves stick. If you have this problem put air tool oil or motor oil on the brass spools behind the handles and 10 drops in the "IN" port. If you have any questions feel free to call 800-299-7773 or email [jay@airejax.com](mailto:jay@airejax.com). Thank you for choosing Aire Jax.